

# **XTZ SUB AMP1**

Subwoofer Amplifier

User manual

© 2009 XTZ AB, www.xtz.se

### Table of contents

	Page
Contents	3
About XTZ	4
Technical presentation	5
Preparations	5
Practice of sound / Installation and placement tips	6
Mounting and connection tips	8
Functional reference	9
Technical specifications	11
Service & Support	12

#### **Contents**

#### **Contents**

XTZ SUB AMP1 offers some possibilities, so in order to utilize your new loudspeaker in the best way; you should carefully read through this manual before using the loudspeaker for the first time. It may take some patience in order to make the loudspeaker sound optimal.

If you have no previous experience of these kinds of installations, or if you have any questions, feel free to contact our free of charge support and we will help you. (See further under the heading of **Support** on the last page of this manual).



### **About XTZ**

#### **Philosophy**

Our reference and starting point is to recreate a natural sound, but also in respect to the fact that acoustics always is a matter of taste.

XTZ Goals	Our main goal is to provide the best value for money.	
	Our concept:	
	- Cut down the numbers of middlemen	
	- Put more money on product quality and less on advertising.	
	- Manufacture cost-effective in large volume	
	- Provide perfect technical solutions	

#### **Contact us**

Website: www.xtz.se E-mail: info@xtz.se

### **Technical presentation**

SUB AMP 1 works just as good for those who want to power the passive subwoofers (XTZ 99 W10.17P) or any other subwoofers. SUB AMP1 can be perfect as a amplifier for bi-amping for full range speakers

By using one or two subwoofers (with correct placement), it is often easier to get a better frequency response.

#### **Amplifier**

The XTZ Sub Amp 1 is equipped with a powerful 300 watt amplifier with a large heat sink for effective cooling. For professional use (studio, PA etc), it is equipped with a balanced input. The terminal connectors are gold plated and very solid.

To achieve a high power and a long durability, the amplifier use a large toroidal transformer, large electrolytic capacitors and Toshiba bipolar transistors in the output stage.

The active amplifier also provides a variety of adjustment options, not possible to obtain using a passive filter. These include phase, frequency, high pass filtering, volume etc.

By using these settings, the main amplifier is relieved and only needs to drive the midrange and treble. This usually results in lower distortion and the risk of damages on it is lowered.

### **Preparations**

#### Unpacking

Carefully unpack the speaker, and pay attention so you don't break anything. If possible, save the packing box for future transportations. If there should be damage on the loudspeaker, please contact your retailer.

Check that the mains voltage marking on the back panel matches your local mains voltage.

If the product is cold, wait to connect the power cable till it reaches room temperature. If you don't do this you can cause damage of the product.

#### Accessories

Main power cable

User manual

Logotype

Robber feet

### Practice of sound / Installation and placement tips

This chapter contains common information on loudspeaker placement and installation.

This is general rules, so there are exceptions of some rules

# In which room do you achieve the best sound?

No matter how good the equipment is, in the wrong listening environment it will inevitably sound bad. There are some basic rules concerning a proper loudspeaker installation:

#### Reflections

Carpets, curtains and soft furniture absorb mid range and high frequency sound, and this is preferable. Big empty area, on the contrary, reflects it and produces hard reflections that may lead to blurry dialogue. Apart from colouring the sound, also the perspective of the sound will deteriorate. Reflections in the room can roughly be compared to the reflections that yield ghost pictures on a TV screen.

# **Amplification of bass frequencies**

A loudspeaker that is placed near a wall, ceiling or floor will amplify lower frequencies in a sometimes not desirable way (since it may lead to an indistinct sound recreation). This amplification becomes even more obvious if the loudspeaker is placed near a corner. Thus, for a sound as clear as possible, the loudspeaker should be placed at least 30 cm (about 12 inch) away from the wall

Some constructions are made to be placed closed to a wall.

#### **Room dimensions**


Quadratic rooms or rooms where the length is exactly twice as long as the width should be avoided, since they may create unwanted resonance.

#### **Furniture**

Be aware that furniture may vibrate and thus create bad sound at loud bass.

#### Front speakers

To get the best result the front speakers should be placed symmetrical in front of the listener. The distance between the front speakers should be around 80% of the distance to the listener. In other words, the recommended angle between the front speakers should be 45°



#### **Angling?**

Either you can have the loudspeakers angled in towards the listener or you can have them directed straight ahead. Some loudspeakers sounds better when angled, but this may also depend on reflections from the side walls. By angling the loudspeakers inwards, you decrease unwanted reflections and thus you get a better stereo perspective.

# Placement of the subwoofer

The placement of the subwoofer in the room dramatically affects the overall frequency response and sound level of the system. At low frequencies the effect of the room is strong. Even a slight change in the subwoofer's location can make a significant difference in the frequency balance. Patience and experimentation is needed to find the optimal placement. The placement affects the phase difference between the main loudspeakers and the subwoofer.

Subwoofers often get a more linear frequency response placed in a corner.

#### The correct height

If the loudspeakers are small, they should be placed on stands or tilted so that they are on the same level as the ears.

#### **Cables**

Try to keep them as short as possible. By its electrical parameters, a long conductor will have a bigger influence on the sound than a short one. The subwoofer cable should be shielded, to avoid noise.

Make sure that all connections are clean and not oxidised. All connections should be mechanically stable, both power, signal and loudspeaker cables. Signal cables should be separated from other cables.

#### **Finally**


Please remember that good sound is a matter of taste, so you have to experiment to obtain your favourite one. We wish you best of luck!

# Mounting and connecting tips

Mounting alternatives	SUM AMP1 is constructed to be placed lying down or standing up. Place the logotype in same direction as SUB AMP1	Mount the feet on the side you want to be down.
Connect using the correct phase	Always connect using the correct phase, from the +-pole on the amplifier to the +-pole on the loudspeaker and corresponding for minus (-).	If you by accident connect the other way, there is no risk of damage. However, the sound will not be correct, especially in the lower frequencies.
Overload	With high power load under long time there is risk of overloading the driver and/or the amplifier.	If you play extremely loud for a long time there is a big risk that you destroy the product.
Load	We recommend that no more than 2pcs of 8 Ohms subwoofer should be connected to SUB AMP1.  This is because the impedance should be extremely low.	

#### **Functional reference**

#### XTZ SUB AMP1 Rear panel



#### Main switch (ON, OFF)

Power switch. Press down "I" to power on and the indicator will be lighted. Press "o" to power off. Make sure it is set OFF when connecting / disconnecting cables. There is an automatic switch on the subwoofer. When it has signal in, it will switch on and consequently switch to standby (this is indicated by the LED, which turns blue when standby is present) when no signal is present (after a certain time period). Therefore, you can have it ON constantly.

To obtain the optimal sound, you should let the subwoofer be in ON mode. The amplifier will then immediately have the right working temperature from the beginning. Turn off the subwoofer if it is not in use for along period.

#### **VOLUME**

Controls volume level of subwoofer. **Be gentle on the volume knob**; please remember that certain sound signals may contain alot of energy.

#### **FREQUENCY**

Variable control from 40Hz to 250Hz provides (-3dB) optimum setting of subwoofer crossover frequency to match crossover frequency of Home Theatre components.

#### EQ 1

Increases 7dB @ 25Hz

Excessive use of EQ can lead to damage of the subwoofer, when used at high volumes

#### EQ 2

Increases 7dB @ 50Hz

Excessive use of EQ can lead to damage of the subwoofer, when used at high volumes EQ 2 and High Pass filter should not be used at same time.

PHASE	o-180 phase adjustment	
HIGH PASS	Switch ON and the high pass are available. Switch OFF and the high pass are unavailable.	The high pass crossover removes the deepest part of the bass spectra. This is helpful in many rooms, since they heavily amplify the deep bass tones, which may lead to uncontrolled bass.
BALANCE	Balanced input	
LINE IN	Line-level inputs to subwoofer. Use these RCA jacks to connect audio signals from line-level outputs on a receiver, preamplifier, television set or surround sound decoder. If only a mono (single) subwoofer output is provided, connect it to either of input jack.	Remark: By connecting both lines in inputs to the same signal, you increase the level by 3 dB. Certain types of simpler low level audio cables may create a noise in the subwoofer. We recommend double shielded low level cables to be used.
SPEAKER IN	Stereo high-level inputs to subwoofer. Use these terminals when line-level connections are not available from receiver, preamplifier or surround sound decoder.	
AC INPUT	Connect to regular 230 V / 50 Hz.	
OUT (SPEAKER OUT)	High Level OUTPUT to speaker/passive subwoofer. Stereo high-level inputs to subwoofer. Use these terminals when line-level connections are not available from receiver, preamplifier or surround sound decoder.	

# **Technical specifications**

<b>Construction type</b>	Amplifier Class AB	
Dimensions	376 x 396 x 225 mm (HxBxD)	Feet add 22mm
Weight	16 kg/pcs	
Frequency response	10-250 Hz	
Connections	Gold plated RCA XLR Balanced input Speaker input: Banana plug/Pole screw Speaker output: Banana plug/Pole screw	
Power amplifier	300 W RMS in 4 ohm 400 W RMS in 2 ohm	
Connections and settings	<ul> <li>Stereo low level input, balanced input and high level (speaker) input.</li> <li>Auto on</li> <li>Phase selector o to 180 degrees.</li> <li>Boundary frequency control (40-250Hz)</li> <li>Volume control</li> <li>High pass switch</li> <li>Heavy duty screw terminal connectors</li> </ul>	

### Service & support

Service	If you need service contact your local dealer. You are always welcome to contact us if you have problems with product by e-mail: support@xtz.se Webpage: www.xtz.se	ALWAYS pack the product / part very carefully. Unfortunately damages during transportation are very common. If the package is weak, the transporting company does not compensate damages. Always enclose a copy of the receipt and a description of the defect.
Support	Please contact our "free-of-charge" support if you need installation advice, or if any problems occur during the installation.	

Contact us by e-mail **support@xtz.se** and include your phone number if you require help, and we will ring you back.